

GEIGER

Taper™ Chair

Seat Height

LOWER RIGHT SIDE OF SEAT



↑ TO RAISE
Take your weight off chair,
lift tab up.

↑ TO LOWER
Lift tab up while seated.

At the proper height, your feet should
rest flat on the floor with upper and
lower leg forming a 90 degree angle.

Forward Tilt

HORIZONTAL TAB ON LEFT FRONT SIDE OF SEAT



↓ TO ENGAGE
Recline and flip lever down.

↑ TO RELEASE
Recline and flip lever up.

Engage forward tilt to support the thigh's
declined posture when performing
intensive tasks, such as keyboarding.

*Note: When using forward seat angle, increase
seat height slightly for added comfort.*

Harmonic™ Tilt Tension

KNOB BELOW RIGHT FRONT SIDE OF SEAT



⌚ TO INCREASE
Turn knob clockwise.

⌚ TO DECREASE
Turn knob counterclockwise.

Set the tilt tension to control the
resistance you feel when reclining.

Tilt Limiter

VERTICAL TAB ON LEFT FRONT SIDE OF SEAT



↑ TO ENGAGE
Recline and move lever up to define
the limit of recline.

→ TO RELEASE
Lean forward and press lever back.

*Engage the tilt limiter when you want to sit in
an upright or partially reclined position.*